

Partner: Hunter Douglas
Models: PowerView Gen3
Device Type: Shades/Drapes Controller



GENERAL INFORMATION

SIMPLWINDOWS NAME:	Hunter Douglas PowerView Gen3 Command Processor v1.0
CATEGORY:	Shades/Drapes
VERSION:	1.0.0
SUMMARY:	This module controls IP communication with a Hunter Douglas PowerView Gen3.
GENERAL NOTES:	<p>This module acts as the primary communication interface to a single PowerView Gen3 controller. If the control program needs to control multiple devices, a separate module is required for each device.</p> <p>The module has safety logic incorporated. For instance: If the primary position is at 0% (closed) and the tilt is at 50% (half open), changing the primary position may default change the tilt to 100% (open). Some of this will depend on how your shades are set up.</p> <p>Known Issues with tested firmware:</p> <ul style="list-style-type: none">• No motion-start event for primary motor of shade capability type 9.• Current positions not always end on target position. <p>Module developer contact: Control Concepts, Inc. (201) 797-7900 support@controlconcepts.net</p>
CRESTRON HARDWARE REQUIRED:	Crestron 3-Series or 4-Series processor.
SETUP OF CRESTRON HARDWARE:	This module is required to use the Hunter Douglas PowerView Gen3 Scene Control v1.0 and Hunter Douglas PowerView Gen3 Shade Control v1.0.
VENDOR FIRMWARE:	Hunter Douglas PowerView Gen3 - 3.1.398
VENDOR SETUP:	N/A



Certified Module

Partner: Hunter Douglas
Models: PowerView Gen3
Device Type: Shades/Drapes Controller



PARAMETERS:

IP_Address	The network address of the device to control.
-------------------	---

Partner: Hunter Douglas
Models: PowerView Gen3
Device Type: Shades/Drapes Controller



CONTROL:

Connect	D	Establishes communication with the cloud service and starts the initialization for all registered device modules.
Disconnect	D	Stops communication from the command processor to the cloud service.
Debug	D	Set high to enabled debug messages.
IP_Address	S	The local IP/hostname for the master gateway. This serial signal is optional if the parameter is used.

Partner: Hunter Douglas
Models: PowerView Gen3
Device Type: Shades/Drapes Controller



FEEDBACK:

Is_Communicating

- D Indicates the command processor is communicating with the cloud service when the signal is high, or not communicating when the signal is low.

Is_Initialized

- D Indicates the command processor is synchronized with current device state of all registered device modules when the signal is high, or not synchronized with current device state when the signal is low.

Partner: Hunter Douglas
Models: PowerView Gen3
Device Type: Shades/Drapes Controller

**TESTING:**

OPS USED FOR TESTING:	CP3 v1.8000.4666.20418
	MC4 v2.7000.00040
SIMPL WINDOWS USED FOR TESTING:	4.1800.14
CRES DB USED FOR TESTING:	210.0000.003.00
DEVICE DATABASE:	200.14000.001.00
SYMBOL LIBRARY USED FOR TESTING:	1156
SAMPLE PROGRAM:	HunterDouglas PowerViewGen3 Demo v1.0.smw
REVISION HISTORY:	v1.0 – Initial Release